




# E-Z UP® INSTANT SHELTERS®


## HOW TO SET UP YOUR E-Z UP® INSTANT SHELTER® SCREEN ROOM™

### SCREEN ROOM™ SET UP:


- 1 Set up your E-Z UP® Instant Shelter®. Before starting to hang the screen room, fold the top fabric back halfway at each corner. The screen will wrap around each corner, fitting under the top and against the frame.



- 2 Make sure that the screen room is unzipped and the ties are toward the top. Begin on the side of the E-Z UP® where the zippered entrance will be, tie one end of the screen room to the upper truss frame toward the middle of the truss wall.




- 3 From the inside, go to the next tie closest to the entrance. Tie screen to top outside truss near corners of the frame and repeat until all four sides of the E-Z UP® are covered. Additional tie hooks are also located around each of the frame legs for a snug fit.




Middle

From the outside of the screen room, pull top back down over the screen at corners. Ends of screen room can now be zipped together as the entrance and exit.




Corner

- 4 Stake down the E-Z UP® Instant Shelter® by inserting a stake through the grommet hole in the screen room and through the hole located in the E-Z UP® footpad. Push the stake securely into the ground. Repeat on remaining legs and grommet holes of screen room.




### SCREEN ROOM™ TAKE DOWN:


- 1 Remove all stakes securing screen room and E-Z UP® legs.



- 2 From the outside of shelter fold top fabric back from each corner. Completely unzip screen room entrance.



- 3 Untie one of the zippered ends. Gather screen from bottom to top. Continue untying until the screen room is gathered.



**WARNING: Handle the screen material carefully to avoid rips or tears. Keep fire or lighted objects away.**

### IMPORTANT INFORMATION

1. Always stake or weight down your E-Z UP® INSTANT SHELTER®. Take down if heavy winds threaten to blow.
2. Use a mild soap (not detergent) and water for cleaning.
3. Let the E-Z UP® INSTANT SHELTER® top, frame and screen room dry completely before closing or storing.
4. The E-Z UP® INSTANT SHELTER® is designed as a temporary shelter. We do not recommend leaving it up for extended periods of time. Do not leave the E-Z UP® unattended.
5. Handle screen room with care.  
**Do not store stakes with screen room.**
6. Save instructions for future reference.

### INTERNATIONAL E-Z UP, INC.

1900 Second Street, Norco, California 92860  
(951) 279-0999 • Fax (951) 279-0888 [ezup.com](http://ezup.com)

**800-45 SHADE**  
**800-457-4233**